## HEADLAMP TELL-TALE LAMP INSTRUMENT PANEL III DIA. DRILL AT ASSY. III DIA. DRILL AT ASSY. III DIA. DRILL AT ASSY. SPEEDOMETER MODEL CJ-2A

INSTALLATION PROCEDURE

The indicator is installed in the instrument panel and connected with the foot dimmer switch.

The installation is very simple.

This lamp is a safety feature which indicates when the HIGH BEAM lights are being used.

Measure 2-5/64" up from the instrument panel fuel gauge and center punch. Drill an 11/32" hole.

Pass the threaded end of the light socket through the hole from the rear side of the instrument panel and attach it with the lockwasher and threaded chromium plug containing the red lens or indicator. Pass the light cable through the opening where the wiring harness

Test the installation by turning on the lights and operating the dimmer switch. When the

goes through the dash and attach it to the high beam terminal on the foot switch. Attach

lights are switched to the high beam, the tell-tale lamp should light.

Service Dept.

WILLYS-OVERLAND MOTORS, INC.

Form 642543 3M 1-46 Para. Toledo, Ohio